



Anderson X-TERRA Shaft Instructions

Fig.1



To install your X-TERRA housing onto the Anderson Shaft you must first remove the screw on the side of the grip. After the screw is removed, pull the housing out of the stock handle.

Fig. 2



Your Anderson Shaft comes with a bushing. Install this bushing over the post on the X-TERRA control housing and align the screw hole in the bushing with the one on the post.

Fig. 3



Install the X-TERRA housing into the end of the Anderson Shaft grip and install the screw in the side. The screw hole on the Anderson Shaft is under the grip. You must roll down the grip to install the screw.

Fig. 4



Install your lower rod and coil onto the shaft

Anderson Detector Shafts
P.O. Box 727
Ridgeway, Ontario
L0S 1N0
Canada