



ANDERSON CTX 3030 LOWER ROD INSTRUCTIONS

Thank you for purchasing the CTX 3030 Lower Rod from Anderson Detector Shafts. In order to use our lower rod you must first remove the plastic spine which is attached to the connector end of the Minelab coil cable. Simply grasp the coil cable in one hand while pulling the cable free from the spine with the other hand. Retain the plastic spine for use with the original Minelab lower rod if desired. A set of washers and washer shims are included with our lower rod. Use the washer shims if you would like to adjust the tightness of the coil fit to our lower rod.

